

COLOR VISION Spectral Imaging Colorimeter SV-2000

• Spectral Imaging Colorimeter

SV-2000 is a new spectral imaging colorimeter launched by Color Vision. By integrating a spectrometer, SV-2000 can not only capture the luminance and chromaticity data of the entire image, but also obtain spectrum data to improve the accuracy of the imaging colorimeter measurements.

At the same time, the spectrometer data can also be used to calibrate the imaging colorimeter, providing customers with higher accuracy and greater calibration convenience. The 20-mega pixels allows customers to quickly measure the spatial luminance and chromaticity distribution of samples, providing high-resolution details for testing.

SV-2000 can be widely used in measuring/testing of display products such as FPD display/vehicle display/backlight/Micro-LED/Micro-OLED.

SV-2000 is not only perfect for laboratory testing that requires high precision, but its fast measurement is also excellent for mass production line testing.

• Applications

- ◇ Luminance/chromaticity/uniformity measurements for Micro-LED/Micro-OLED/Mini-LED/ OLED/LCD display
- ◇ Testing of FPD screen light leakage, Mura and other defects
- ◇ BLU backlight luminance/chromaticity/uniformity measurements


• Accuracy Guaranteed

- ✓Excellent for measuring Micro-LED/Micro-OLED/Mini-LED/ OLED/LCD and other display products;
- ✓Various factory calibrations available to ensure measurement accuracy and stability;
- ✓Built in ND filter wheel enables various luminance measurement range;
- ✓User calibration provides greater flexibility;




• Features


- ◇ Integrated spectrum and imaging colorimetry measurement
- ◇ 20 mega pixel high resolution
- ◇ Easy to operate, complete automatic exposure test with one click
- ◇ Synchronize frequency option to eliminate the error of periodic signal measurement
- ◇ Pseudo-color image for intuitive evaluation of luminance and chromaticity uniformity
- ◇ Flexible settings for various points of interest
- ◇ Easy data analysis/export



▲ Pseudo-color map



▲ Macro imaging captures sub-pixels details



▲ Point of Interest

| 选择 | 名称 | 类型 | X坐标 | Y坐标 | 平均值 |
|-------------------------------------|---------|--------|------|------|----------|
| <input checked="" type="checkbox"/> | Point 2 | Circle | 763 | 1840 | 54.72433 |
| <input checked="" type="checkbox"/> | Point 3 | Circle | 3223 | 1884 | 55.97514 |
| <input checked="" type="checkbox"/> | Point 4 | Circle | 742 | 2648 | 54.78104 |
| <input checked="" type="checkbox"/> | Point 5 | Circle | 2037 | 2662 | 55.13629 |
| <input checked="" type="checkbox"/> | Point 6 | Circle | 2022 | 1862 | 55.09698 |
| <input checked="" type="checkbox"/> | Point 7 | Circle | 3252 | 2662 | 55.764 |
| <input checked="" type="checkbox"/> | Point 8 | Circle | 749 | 3390 | 54.20019 |

▲ Data Analysis

● Specification

| | |
|----------------------------------|--|
| Brand & Model | COLOR VISION SV-2000 |
| Sensor | Back-illuminated CMOS |
| Resolution | 20M, 5520*3680 |
| Cooling*1 | TEC Cooling + air cooling |
| Luminance Range*2 | 0.001-10,000,000cd/m ² |
| Exposure Time | 0.1ms-5s |
| Luminance Accuracy*3 | ±3% |
| Chromaticity Accuracy*3 | x,y ±0.003 |
| Spectrum Range | 380-780nm |
| Spectrum Luminance Range | 0.1-10,000,000cd/m ² |
| Spectrum Luminance Accuracy | ±2% |
| Spectrum Chromaticity Accuracy*3 | x,y ±0.002 |
| Sync Frequency | Set the Sync Frequency to match the sample refresh rate |
| Software | Color Vision Test Software |
| Test Function | Luminance, Chromaticity, Uniformity, CIE1931, CIE1976 Chromaticity coordinates, Tristimulus, CCT, dominant wavelength etc. |
| Data Interface | USB 3.0 |
| Weight | About 2.5 kg |
| Working Environment | 0-35°C, 10-80% non-condensation |
| Power Supply | 100-240V, 50-60Hz |

*1 Thermoelectric Peltier Cooling + air cooling, working temperature configurable

*2 High luminance measurement requires an optional ND filter, minimum luminance requires a long exposure time

*3 Under test conditions of standard A light source 100cd/m²

The contents of this document are subject to change at any time, and no person may derive any rights from the contents of this document, all rights reserved. No part of this document may be reproduced, stored in a database or retrieval system, or published electronically, mechanically, in print, in photographic print, on microfilm, or by any other means without the prior written permission of the publisher.